

3. Change the direction of rotation (see figure B)

orward turn, push the steering pole to the bottom (move to the aft side), which can be used for drilling and screwing. everse, push the side marked of the steering pole to the bottom nove to the right side), which can be used for loosening and riping out the screw.

Marning: The machine will not change direction until it is

stationary **1. Variable Speed (see Figure C)** I gear speed: high torque/low speed, used for drilling thicker bits

r screwing. gear speed: low torque/high speed, used for drilling smaller

When the mechanical gearshift lever is unable to move due to gear collision, press the switch lightly to rotate the motor and then shift.

Warning: The machine will not change its speed until it is

completely stationary.

5. Installation or removal of drill bits (see figure D)
Hold the sleeve of the back half of the chuck and turn the sleeve
of the front half counterclockwise to open the chuck. Put the bit
into the chuck and push it to the bottom as far as possible. Hold
the sleeve ring clockwise and rotate the sleeve to tighten the
chuck


when disassembling the chuck, just hold the sleeve ring and

Totale the sleeve counterclockwise.

6. Setting Torsion (see figure E)
Turn the torsion control ring to adjust the machine's torsion.
When the number 1 on the torsion control ring is aligned with the knowledge arrow above the machine, the torsion is the smallest.
When the mark on the torsion control ring is aligned with the indicator arrow above the machine, the torsion is the largest.

### The reference for setting use is as follows

1-7	Rotary Small Screw		
8-14	Screw into soft material		
15-20	Screw in soft and harder material		
8	High Strength Drilling		



7. Spindle self-locking function
The spindle self-locking function enables the machine to operate
as a manual tool. When the battery pack power is exhausted, the
machine can be manually rotated to tighten or loosen the screw.
At this time, the chuck is fixed.

At this time, the chuck is likeu.

8. Use LED lights

Press the machine switch to turn on the working lamp, loosen the switch to turn off the working lamp.

LED lights can greatly improve the regularity of use in dark or

closed areas.

9. Battery Pack Electricity Measurement
Electricity Display When Four Lamps are Fully Activated. When only one or no light is on, please charge the battery.

10. Drilling operation

Men drilling holes on the surface of hard materials, a pointed punch and a hammer can be erials, a pointed punch and a hammer can be used to mark the place where the drill is to be drilled in order to prevent the bit from slipping. Hold the

in order to prevent the bit from slipping. Hold the hand electric drill tightly, align the drill point with the mark, press the switch for drilling operation, and drill with proper pressure. Do not use excessive pressure or offset pressure to make the hole diameter larger.

\( \frac{\Lambda}{\text{When drilling concrete and stone, please use cemented carbide drills. When drilling metal materials, use high-speed steel drills in good condition. When using short screw batches, please use

when using short screw batches, please use magnetic connecting rod (excluding). When twisting the screw, apply a little soap or other lubricant on the screw thread so that it can be easily screwed in.

screw thread so that it can be easily screwed in.

11. Overload protection
When overload occurs, the motor stops running. The
machine is immediately unloaded and cooled for 30
seconds at the maximum idle speed.

12. Discharge protection
The machine is equipped with discharge protection
circuit. When the battery power is insufficient, the
protection circuit opens and the machine stops
turning.

### Maintenance

Your electric tools do not need to be lubricated or

Don't use water or chemical cleaners to clean your electric tools. Just wipe them with a dry cloth. The tools should be stored in a dry environment and the ventilation of the motor should be kept clean. Try not

# **Question Answer**

QUESTION ANSWER

1. Why do you press the switch and the machine doesn't work?
There is a steering pole at the top of the switch, which is in the locked position. Put it in the position where it needs to be turned. When the switch button is pressed, the machine will start to turn.

2. Why does the electric drill stop running before the screw is tilothened?

active the screw is tightened?

At this time, please adjust the torsion adjustment ring between the fuselage and the chuck. The torsion corresponding to position 1 is the smallest and that corresponding to position 19 is the largest. The position is used for drilling, and this problem can be called the difference of the control of the solved by adjusting the torsion adjusting ring to a

short time? As mentioned above, if a battery pack is left unused several times of charging and using, this situation will be improved. When doing heavy work, such as screwing large bolts into hardwood, the battery pack will also consume electricity very quickly. Do not charging in the environment below 0℃ or above 45℃

3. Why does the same battery pack work for a long or

th is will also affect the performance of the batter

# **Environmental protection**




n response to environmental protection, damaged machines, accessrioes and packaging naterials must be classified in detail to facilitate and recycle. n order to facilitate classification and recycling, all plastic parts are marked with material.

### **Component list**

Serial No.	Name	Number	Serial No.	Name	Number
1	M6*25 screw	1	25	Tapping screws	2
2	Drill Chuck	1	26	annular gear	1
3	Torsion cup	1	27	planet carrier	1
4	Internal thread ring	1	28	planetary gear	3
5	Torque spring	1	29	annular gear	1
6	Torque adjustment shim	1	30	Back cover	1
7	6800Z Plane bearing	2	31	Motor connecting plate	1
8	Output shaft	1	32	Motor gear	1
9	Single end cylindrical pin	6	33	Motor	1
10	Front cabinet	1	34	Mechanical variable Speed Button	1
11	ø10 External plier	1	35	left shell	1
12	Lock shaft Hexagon piece	1	36	left label	1
13	Auto-locking block	1	37	Shift piece	1
14	Pin	6	38	Lampshade label	1
15	Axis lock planet carrier	1	39	Power indicator lampshade	1
16	annulargear	1	40	Plug	1
17	planetary gear	5	41	steering lever	1
18	Interstage gasket	1	42	Brushless DC switch	1
19	planet carrier	1	43	right shell	1
20	planetary gear	5	44	right label	1
21	Back cabinet	1	45	ST3*14 Cross recessed pan head tapping screws	11
22	ST3*12 Cross recessed pan head tapping screws	4	46	20V Battery	1
23	Gasket	2	47	Portable belt	1
24	Speed frame	1			

<sup>\*</sup>This list just reference.



Company: Hunan Jiangyun Intelligent Technology Co., Ltd

Website: www.brototools.com

Add : Software Centre Building, Lugu Street, High-Tech Development Zone, Yuelu District, Changsha, Hunan, China

BROTO Hunan Jiangyun Intelligent Technology Co.,Ltd MOTOR

Note:Please read the instructions carefully before using the machine.

Brushless Lithium Power Drill CQ-0015

Brushless Lithium Power Drill CQ-0015

Brushless Lithium Power Drill CQ-0015

Brushless Lithium Power Drill CQ-0015 Instruction

tool" refers to either mains driven (wired) power tools or battery driven (wireless) power tools.

A. Workplace safety

1. Keep the working area clean and bright. Cluttered and dark Spaces can cause accidents.

2. Do not operate power tools in an explosive environment, such as flammable liquid, gas or dust Sparks from power tools can ignite dust or gas.

3. Keep away from children and bystanders when operating power tools. Lack of concentration can cause you to lose control of your tools.

B. Electrical safety

1. The electric plug must match the socket. The plug must not be modified in any way. Grounding power tools should not use any conversion plug. Unmodified plugs and matching sockets will reduce the risk of electric shocks.

2. Avoid hympan content with exercisions.

Water entering power tools increases the risk of electric shocks.

4. Do not abuse the flexible wire. Never use the flexible wire to carry, pull the power tool or pull out its plug. Keep flexible wire away from heat sources, oil, sharp edges or moving parts. Damaged or wound cords increase the risk of electric shock.

5. Use extension cords suitable for outdoor use when using power tools outdoors. Wires suitable for outdoor use will reduce the risk of electric shocks.

6. If operation of power tools in wet conditions cannot be avoided, use a power supply with residual current device (RCD) protection.

7. Personal safety

1. Be alert, pay attention to what you are doing and stay awake when operating power tools. Do not operate power tools when you are tired or have reactions to drugs, alcohol or treatment. Momentary instention in handling power tools can result in serious injury.

2. Hose passed passed in extending the power tools and scessories, tool heads, etc.

7. Select power tools. Power tools and and scessories to dontout the safe prepaired.

8. Before making any adjustments, replacing accessories, or storing power tools. Serior the power tools. As to required.

8. Before making any adjustments, replacing accessories, or storing power tools. Store unused power tools. Out of the reach of children and do not allow them to be operated by every tools can be dacidentally starting power tools out of the reach of children and do not allow them to be operated by every tools can be dacidentally starting power tools and accessories. Check for moving parts that are in place or stuck, parts that are in place or stuck, parts that are inplaced before use. Many accidents are caused by poorly maintained power tools.

8. Keep remove the plug accessories, tool sout of the reach of children and do not allow them to be operated by every tools can be dacidentally starting power tools.

9. Maintain power tools and accessories tools can be dacidentally starting power tools.

9. Maintain power tools and accessories tools can be d

inattention in handling power tools can result in serious injury.

2. Use personal protective devices. Wear goggles dust masks, non-slip safety shoes, helmets and hearing protection can be used under appropriate of paper and to dangerous situations.

can result in electric shock, fire and/or serious injury.
Save all warnings and instructions for review.
In all of the warnings listed below, the term "power tool's connected.Wrenches or keys left on the rotaling parts of power tools can cause personal injury.

bollys and matching sockets will reduce the risk of electric shocks.

2. Avoid human contact with grounding surfaces, such as pipes, heat sinks, and refrigerators. There is an increased risk of electric shock if your body touches the ground surface.

3. Do not expose power tools to rain or moisture. Water entering power tools increases the risk of electric shocks.

Rechargeable drill safety warning
I. If the tool is provided with an auxiliary handle, use the auxiliary handle. Uncontrolled use of the tool may cause personal injury.

2. If the working attachment may come into contact with hidden wires during operation, hold the working insulated gripping surface. When the work accessory comes into contact with the "live" wire, the exposed metal part of the power tool may also become "live" and give the operator an electric shock.

3. Make sure your feet are standing still. When using tools from a height, make sure no one is below you.

4. Hold tools tightly.

5. Keep your hands away from the rotating parts.

6. Do not operate the tool without being looked after. You can use this tool only by hand.

7. Do not touch the drill or work immediately after operation, these parts may be very hot and burn your skin.

8. Keep handle and holding surface dry, clean and free from grease.In the event of an accident, a slippery handle does not guarantee secure grip and control of the tool.

E. Battery tools and precautions

1. Use only the charger battery specified by the manufacturer. Chargers that work in one battery pack may be a fire hazard when used in other battery

injury and fire.

3. When the battery pack is not in use, keep it away

3. When the battery pack is not in use, keep it away from other metal objects such as paper clips, coins, keys, nails, screws, or other small metal objects to prevent one end of the battery pack from connecting to the other. A short circuit at the end of the battery pack may cause combustion or fire.
4. Under abusive conditions, liquid may spill out of the battery pack. Avoid contact. If accidental contact with liquid, rinse with water. Seek medical attention if fluid touches the eye. Liquid spilled from the battery may corrode or burn.

may corrode or ourn.

5. Do not use damaged or modified batteries or tools.Damaged or modified battery packs can have unpredictable results, resulting in fire, explosion, or injury.

6. Do not expose the battery pack to fire or high temperature. Exposure of the battery pack to fire or high temperatures above 130°C may cause an explosion.

exposion.

F. maintenance

1. Use the same spare parts to repair power tools by professional maintenance personnel. This will ensure the safety of the power tools being repaired.

2. Never repair a damaged battery pack. The battery pack can only be repaired by the manufacturer or its authorized service provider.

# Rechargeable drill safety

# Keep these manuals properly

because you are familiar enough with the product (due to repeated use). Improper use or failure to follow the safety rules in this manual can result in serious personal injury.

### Marks

Warning label



Do not place in rain or water




Please wear a dust mask



The body of the product (excluding battery) does not contain toxic or harmful battery) does not contain toxic or harmful substances or elements, and it is a green product. It can be recycled after waste, and should not be discarded at will.






# 1.Chuck 2.LED light 3.on/off switch 4.Battery pack 5.Battery lock knob 6.Electric quantity display 7.Steering lever 8. Torsion adjusting ring 9 Mechanical variable Speed Button(front fast and back slow) \*Some of the accessories mentioned in the drawings or words are not included in the scope of supply. \*\*Buckle can be installed(this model does not include buckle)

# Parameter

Voltage		20V
No-load speed		0-450/0-1600RPM
Torsion adjustment gea	ar	20+1
Max chuck capacity		13MM
Max drilling capacity	Steel	13MM
wax drilling capacity	Wood	40MM
Battery		4000mAh/6000mAh

high quality accesssories of well-know brands and choose the accessories that are suitable for your work. Please refer to the attached package description before use, you will get more methods and help to use.

# **Product Usage Description**



# Operational guidelines

: Before using the machine, please read the instructions Note: Before using the machine, please read the instructions carefully.

Purpose: This tool is used to screw or drill holes in wood, metal and plastic.

Charge

The charger and the machine need to be used together. It is strictly prohibited to use other chargers. In high temperature environment or after long-term use, the machine may become hot. At this time, please do not charge immediately, and recharge after the battery is cooled. Otherwise, the service life of the battery will be shortened or the battery can not be recharged due

battery will be shortened or the battery deathers of the coverheating.

When the machine is charged for the first time or not used for a long time, after 2-3 times of charging and discharging, the battery efficiency can reach 100%.

The battery pack can be inserted into the charger in only one direction. Turn the battery pack until it can be inserted into the charger. When the red light of the charger is on, the charging harins


When a full battery pack is inserted into the charger, the smar charger will detect the voltage of the battery pack. When the unlock voltage is not reached, the charger will not charge the battery pack and the red light will not turn green.

stallation/removal of battery packs (see figure A) remove the battery pack, press the lock in front of the battery

### Operation

Operation
 I. Start/close (see figure B)
 Press the switch, start the machine, loosen the machine to stop running. The switch has braking function. When the switch is loosened, the chuck stops turning immediately.
 The force applied on the switch can change the speed, and the range of change is from 0 to the maximum speed. Small force, low speed, easy to control, do not let the machine stop running because it bears too much load.
 Marning: Do not operate at low speed for a long time, or there will be overheating reaction inside the machine.
 Switch lock

2. Switch lock
The switch has lock protection function, which is helpful to reduce the Misstart of the hand drill when it is not in use. By adjusting the steering lever to the median position, the machine can be locked.



Brushless Lithium Power Drill CQ-0015

4 5

Brushless Lithium Power Drill CQ-0015